

REDLER


CC.2
Issue 2

INSTALLATION AND MAINTENANCE

REDLER CONVEYORS AND ELEVATORS

INSTALLATION OF LAGOS 3122 CHAIN

- 1) Make the chain connection by fitting the connecting pin, placing the collar in position and aligning the pin holes.
- 2) Force the spirol pin into the collar.



If the fitting of the pins is too difficult an operation to perform inside the casing of the machine it may prove more convenient to support the links being connected clear of the casing on a bar resting across the side panels. (See diagram below).

