



Main view  
Główny

View to raw-gas input (without bypass)  
Zobacz na wejście gazu surowego (bez obwodnicy)

list of nozzles		
Nr	kind of nozzle	Dimens.
28	temperature (output 4..20mA)	DN50
29	level sensor (vibrating fork)	DN50
30	temperature (indication)	DN50
45	inerting nozzle	DN25

Before mounting the gas distributor (15), the side walls between the gas distributor and the housing walls (11) are insulated. This inner insulation receives no paneling.  
Przed zamontowaniem dystrybutora gazu, ściany boczne między rozdzielaczem gazu, a ścianami obudowy są izolowane. Ta wewnętrzna izolacja nie otrzymuje panele.

Filtry workowe - załącznik nr 1